



1920 Manhasset® Short Stand Cart Assembly Instructions

Hardware Package Contents:

2 pcs -1/2" bolts	16 pcs -5/16" flat washers
4 pcs -1/2" washers	14 pcs -5/16" nuts
6 pcs -1/4" nuts	16 pcs -5/16" bolts
6 pcs -1/4" washers	16 pcs -5/16" lock washers
1 pcs -5" Handle Connector	

Tools Needed:

1/2" Wrench
7/16" Wrench
3/4" Wrench

Before beginning assembly, be sure all parts are present using the parts list on the back of this page. Do not tighten down any of the bolts and nuts completely before assembly of the cart is finished.

1. HANDLE FRAME ASSEMBLY

On a flat surface lay the 2 *Handle Sides* (P/N 1951) with bent ends facing away from each other. Using 4 - 5/16" bolt, washer and nuts, attach 16" *Handle Axle* (P/N 1953) to bottom of *Handle Sides* and set unit aside.

2. END FRAME ASSEMBLY

Lay *End Frame Axle* (P/N 1956) on flat surface and lay *End Frame Sides* (P/N 1955) above *End Frame Axle* to form triangle shape. Using 5/16" bolt and washer, insert bolt/washer through outside edge holes of *Axle* and thread into internal nut of *End Frame Side* (P/N 1955). **DO NOT TIGHTEN COMPLETELY.** Using 5/16" bolt, washer and nut, thread from the bottom of *End Frame Axle* upward through tab hole of *End Frame Side*.

3. ATTACHING BOTTOM RAILS TO HANDLE ASSEMBLY

Using 5/16" bolt, washer and nut, align angled tabs with lower bolt hole sets of *Handle Assembly*. (Make sure the solid surface of the plastic rail guard is facing upward.)

4. ATTACHING END FRAME ASSEMBLY TO BOTTOM RAILS

Slide *End Frame* center pegs under the *Bottom Rails* (P/N 1954B) with the bolt holes of the center peg tabs pointing to the *Handle Frame*. Align with center peg tabs with bolts protruding from underside of *Bottom Rails* and attach using 1/4" nuts.

5. ATTACHING TOP RAILS TO CART

Align bolts protruding from underside of *Top Rails* (P/N 1954T) with bolt holes of *End Frame Assembly* and attach 1/4" nuts. Using 5/16" bolt, washer and nut, thread bolts through bolt holes of *Top Rail* and *Handle Side*. Thread *Handle Connector* (P/N 1952) on to bolts and finish with washer and nut.

6. TIGHTEN ALL BOLTS AND NUTS ON THE ENTIRE CART

7. ATTACHING 6" WHEELS TO CART

Using the 1/2" bolt, place a 1/2" wheel washer on each side of the 6" wheel (P/N 1921) and thread into to the *Handle Axle* (P/N 1953) internal nut and tighten.

SHORT CART PARTS [Quantity] (Part Number)

