



MANHASSET®
Specialty Company
Yakima, WA

MODEL 1920 SHORT STAND CART - POLYETHYLENE RAILS GUARD INSTALLATION

Your Manhasset Model 1920 Short Stand Cart comes equipped with a polyethylene guard to protect to horizontal long rails. Although they can be installed before the stand cart has been assembled, you may find it a little easier to install them after cart assembly.

With your storage cart, you will find two different sets of polyethylene rail guards. The guards with the notched sections on the end (not 8 ½-inches from the end) are to be fitted over the top horizontal rails, with the cutout notched end to be away from the handle end. The polyethylene guards with the cutout notches that are 8 ½-inches from the end are to be fitted over the lower horizontal rails, with the notched areas away from the handle end. With both the upper and lower rails, the polyethylene rail guards are to be installed so that the notched areas of the rail guards lining up (and cover) the area of the rails where the flat-head bolts are welded to the rails' square tubing.

The polyethylene guards, prior to their installation are triangular in shape. The installation requires separating the sides of the guards at one end and pushing them over the horizontal rails – working from one end to the other. You may find it easiest to install the rail guards over the horizontal rails by spreading the end of the rail guard over one of the topside corners of the square tubing (horizontal rails). Once the rail guard is spread, it then can be moved over to the top of the rail, and then by pressing down, the rail guard sides should cover the horizontal rail tube sides. Once this is started, you can then continue pressing the rail guard down over the horizontal rail tubing and moving toward the other end of the rail as it is applied. Once completely installed, it should stay securely in place.