



MANHASSET®
Specialty Company
Yakima, WA

MODEL 1910 STAND CART - POLYETHYLENE RAILS GUARD INSTALLATION

Your Manhasset Music Stand Storage Cart comes equipped with a polyethylene guard to protect to horizontal long rails. Although they can be installed before the stand cart has been assembled, it may be a little easier to install them after cart assembly.

With your storage cart, you will find two different sets of polyethylene rail guards. The guards without cutout notches are to be fitted over the top horizontal rails. The guards with the cutout notches are to be fitted over the lower horizontal rails, with the notched areas lining up with the sections of square tube attached below the lower rails. The end of the polyethylene guards that have the notches approximately 26-inches from the ends are to be installed on the ends of the storage cart toward the handle.

The polyethylene guards, prior to their installation are triangular in shape. The installation requires separating the sides of the guards at one end and pushing them over the horizontal rails – working from one end to the other. You may find it easiest to install the rail guards over the horizontal rails by spreading the end of the rail guard over one of the topside corners of the square tubing (horizontal rails). Once the rail guard is spread, it then can be moved over to the top of the rail, and then by pressing down, the rail guard sides should cover the horizontal rail tube sides. Once this is started, you can then continue pressing the rail guard down over the horizontal rail tubing and moving toward the other end of the rail as it is applied. Once completely installed, it should stay securely in place.